

Quick Manual: Using a Dryer with a Water Reservoir

1. Prepare the Dryer

- Ensure the dryer is plugged in and properly connected.
- Check that the water reservoir is empty.

2. Load the Laundry

- Sort clothes by fabric type and weight.
- Load the drum without overfilling it (about 2/3 full for best results).

3. Set the Program

- Select the drying program suitable for your laundry (e.g., cotton, synthetic, delicate).
- Adjust additional settings (e.g., temperature or duration) if needed.

4. Start the Dryer

- Close the door securely.
- Press the start button to begin the drying cycle.

5. Monitor the Reservoir

- During or after the cycle, check the water reservoir.
- If it fills up mid-cycle, empty it to prevent interruption.

6. End of Cycle

- Once the cycle finishes, open the door and remove the laundry.
- Empty the water reservoir and clean the lint filter.

7. Maintenance

- Regularly clean the lint filter and condenser (if applicable).
- Keep the water reservoir clean and dry when not in use.

For additional assistance, please contact us at +32 479 542 572 (call or whats up)
or call +36 30 693 5676.

Thank you for using our facilities. We hope you enjoy your stay!

Follow these steps

1. Empty the water reservoir and put it gently back
2. Check the filter and clean it by pushing the 'push' button gently, open it and remove all the dirt . Put the empty filter back.
3. Choose the cycle (for example: cotton)
4. Adjust the heat (if needed)

Push the 'sun' button gently to adjust the heat :

Empty sun: cold

Half sun: half warm

Full sun: warm

5. Push the 'timer' button gently to adjust the time of drying (if needed)
6. Push the 'play' button and start the cycle

You can skip step 4 and 5 in case you want and the dryer will do the full cycle (= longer duration).

Thank you for using our facilities. We hope you enjoy your stay!

Follow these steps

